

## Connection box KR8KRL



To install, remove the junction box lid and drill appropriate fitting holes in the mounting surface. Screw the base to the surface.

Protection against outside attack. The tactile switch is used to show the cover has been disturbed.

Connect the TAMPER circuit to the TMP terminals. Once the lid is removed the circuit will be broken.

Ensure all cables are secure and cannot short out to other connections or components.

Max voltage: 125VDC / 230 VAC

Max current: 3A

*Nerival Oy*